

JOY-IT



Tasta-Mini

Mini Wireless Keyboard

Dear customer, thank you very much for choosing our product. In the following we will show you what has to be observed during commissioning and use.

BATTERY

The keyboard is equipped with a 3.7V lithium battery (BL-5B). Use the switch on the right to turn the device on and off.

CONNECTION

To connect, hold **Fn + RF** pressed until the blue LED flashes. The device is now in pairing mode. As soon as the connection has been set up, the LED lights up permanently.

STANDBY-MODE

The device will automatically go into standby after three minutes of inactivity. By pressing any key, the device can be reactivated.

LED INDICATORS

Red LED: Active charging

Blue LED: Bluetooth-connection / low battery

Orange LED: Key and touch indicator

ADJUST CURSOR SPEED

There are three different speeds available. Just press the Fn key, along with the space bar. The orange LED will light up briefly, confirming the speed change.

TOUCHPAD

The touchpad supports multi-touch functions:

Touch with one finger: Left mouse button

Touch with both fingers: Right mouse button

Drag with both fingers: Scroll

The touchpad can also be deactivated.




















Simply press the **Fn + Alt** keys. The orange LED lights up and confirms the deactivation of the touchpad.

BACKLIGHT

To activate the backlight press the **Fn + Win** keys. The lighting can be adjusted in 7 colors.

With the backlight on, press the **Fn + Ö** keys (RGB) to enter the color mode. Swipe from left to right on the touchpad to select a color. To exit the color mode, press the **Fn + Ö** keys (RGB) again.

FUNCTIONKEYS

Button	Function	Combination	Function
	Power	FN + RF	Coupling
	Home	FN + 	Touchpad on / off
	Browser	FN + 	Cursor speed
	R. mouse key	FN + 	Backlight color mode
	L. mouse key		Lighting on / off
	Scroll (two fingers)		
	Back		
	Android menu		
	Mute		
	Play / Pause		
	Backward		
	Forward		
	Volume +		
	Volume -		
	Search		

Information and take-back obligations

Symbol on electrical and electronic equipment



This crossed-out dustbin means that electrical and electronic equipment does not belong in the household waste. You must return the old appliances to a collection point.

Before handing over waste, batteries and accumulators that are not enclosed by waste equipment must be separated from it.

Return options

As an end user, you can return your old appliance (which essentially fulfills the same function as the new appliance purchased from us) free of charge disposal when you purchase a new appliance. Small appliances with no external dimensions greater than 25 cm can be disposed of in normal household quantities independently of the purchase of a new appliance.

Possibility of return at our company location during opening hours

Simac GmbH, Pascalstr. 8, D-47506 Neukirchen-Vluyn

Possibility of return in your area

We will send you a parcel stamp with which you can return the device to us free of charge. Please contact us by e-mail at Service@joy-it.net or by telephone.

Information on packaging

If you do not have suitable packaging material or do not wish to use your own, please contact us, and we will send you suitable packaging.

Support

We also support you after your purchase. If there are any questions left or if you encounter any problems, please feel free to contact us by mail, phone, or by our ticketsystem on our website.

<http://support.joy-it.net>

service@joy-it.net
+49 (0)2845 9360 – 50
(9:30 - 17:00 Uhr)

Declaration of conformity

Hereby the Simac Electronics Handel GmbH, Pascalstr. 8,
D-47506 Neukirchen-Vluyn, confirms as a manufacturer,
that the type of radio equipment "Tasta-Mini"
(Wireless Keyboard) complies with Directive
2014/53 / EU.

The following standards were applied for evaluation:

EN60950-1:2006+A2:2013

EN62479:2010

EN301 489-1 V1.9.2(2011-09)

EN301 489-3 V1.6.1(2013-08)

EN300 440-1 V1.6.1(2010-08)

EN300 440-2 V1.4.1(2010-08)

Frequency range 2400-2483,5 Mhz

Max. transmission power 5 dBm

13.03.2017 Xu Lu (manager)





<http://joy-it.net>

service@joy-it.net